BINTELLI™

2027

## NEXUS 4F STANDARD

# PARTS MANUAL




(866)-542-8677

support@bintelli.com




| 2027 Nexus 4F Parts Manual Overview | |
|---|---|
| 1 | ROOF |
| 2 | WINDSHIELD |
| 3 | FRONT BODY PANEL |
| 4 | DASH PANEL |
| 5 | CHASSIS |
| 6 | FRONT SEAT |
| 7 | REAR UNDERBODY |

# TABLE OF CONTENTS


ROOF PARTS DIAGRAM _____ 1

WINDSHIELD PARTS DIAGRAM _____ 2

FRONT BODY PANEL PARTS DIAGRAM _____ 3

DASH PANEL PARTS DIAGRAM _____ 4-5

PEDAL ASSEMBLY PARTS DIAGRAM _____ 6

CHASSIS PARTS DIAGRAM _____ 7-8

FRONT AXLE PARTS DIAGRAM _____ 9

FRONT AXLE LH PARTS DIAGRAM _____ 10-11

FRONT AXLE RH PARTS DIAGRAM _____ 12-13

REAR AXLE TUBE PARTS DIAGRAM _____ 14

REAR TRANSAXLE PARTS DIAGRAM _____ 15

FRONT BACKREST ASSEMBLY PARTS DIAGRAM _____ 16-17


FRONT SEAT ASSEMBLY PARTS DIAGRAM _____ 18

REAR BACKREST PARTS DIAGRAM _____ 19-20

REAR SEAT AND BODY PANEL PARTS DIAGRAM _____ 21-22


REAR TRUNK PARTS DIAGRAM _____ 23

# ROOF PARTS DIAGRAM





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 1 | 3.06.01.03.02.011 | Nexus 4F Roof | 1 |
| 2 | 4.05.01.42.054 | Nexus 4F Roof Liner | 1 |
| 3 | 4.05.01.41.086 | Front Light Strip End/RH | 1 |
| 4 | 4.05.01.41.085 | Front Light Strip End/LH | 1 |
| 5 | 3.02.01.69.053 | Front Light Strip Mounting Bracket | 2 |
| 6 | 3.02.01.69.015 | Roof Fan Mounting Bracket | 2 |
| 7 | 4.04.06.37.015 | 8" Fan | 2 |
| 8 | 3.02.01.69.017 | Roof Frame Inner Cross Tube | 2 |
| 9 | 4.05.04.03.081 | Roof Gasket 24*260 | 2 |
| 10 | 4.04.06.12.126 | Roof Light | 1 |
| 11 | 4.04.06.12.127 | Roof LOGO Light | 1 |
| 12 | 4.05.01.09.011 | Roof Handle | 3 |
| 13 | 3.02.01.69.055 | B4F Roof Support Tube | 1 |
| 14 | 4.04.06.37.007 | Roof Speaker | 4 |
| 15 | 4.05.01.41.090 | Light Strip Light Shroud 1613mm | 2 |
| 16 | 4.05.01.41.087 | Rear Light Strip End/LH | 1 |
| 17 | 3.02.01.69.054 | Rear Light Strip Mounting Bracket | 2 |
| 18 | 4.05.01.41.088 | Rear Light Strip End/RH | 1 |
| 19 | 4.04.06.12.182 | Light Strip Extrusion 1613mm | 2 |
| 20 | 4.04.06.12.141 | Roof Turn Light/LH | 1 |
| 21 | 4.04.06.12.128 | Roof Brake Light | 1 |
| 22 | 4.04.06.12.142 | Roof Turn Light/RH | 1 |
| 23 | 2.01.02.07.119 | 4F Roof Light Strip Assembly/RH 1613mm | 1 |
| 24 | 2.01.02.07.118 | 4F Roof Light Strip Assembly/LH 1613mm | 1 |

# WINDSHIELD





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 1 | 4.05.04.03.055 | Square Pipe Plug 30*30 | 2 |
| 2 | 3.02.01.69.007 | Laminated Windshield Bracket | 1 |
| 3 | 4.05.02.01.021 | Laminated Windshield | 1 |
| 4 | 4.05.01.13.026 | Side Mirror / RH | 1 |
| 5 | 4.05.01.13.025 | Side Mirror / LH | 1 |
| 6 | 4.05.01.13.006 | Middle Mirror | 1 |
| 7 | 3.02.01.69.028 | Middle Mirror Support | 1 |
| 8 | 4.04.02.11.001 | Windshield Wiper Switch | 1 |
| 9 | 4.04.14.02.024 | Windshield Wiper Arm and Blade | 1 |
| 10 | | | |
| 11 | 4.04.02.03.013 | Windshield Wiper Full Assembly | 1 |
| 12 | 2.01.02.11.053 | Front Windshield Auxiliary Wire-A | 2 |
| 13 | 2.01.02.11.054 | Wiper Motor Power Cord | 1 |
| 14 | 4.04.03.10.165 | Side Mirror Turn Signal Power Cord | 2 |
| 15 | 4.04.03.10.061 | Roof Ambient Light Extension Cord | 1 |
| 16 | 2.06.03.03.010-V2 | Laminated Windshield Assembly | 1 |

# FRONT BODY PANEL





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 1 | 4.05.01.01.043 | Front Underbody | 1 |
| 2 | 4.05.01.41.015 | Front Retainer / RH | 1 |
| 3 | 4.05.01.33.056 | Fuse Box Lid | 1 |
| 4 | 4.04.14.01.006 | Fuse Box Circuit Board | 1 |
| 5 | 3.05.40.003 | Fuse Box Plate | 1 |
| 6 | 4.05.01.41.020 | Front Support / RH | 1 |
| 7 | 4.04.02.06.002 | Reverse Alarm Buzzer | 1 |
| 8 | 4.04.03.10.021 | Radio Cable | 1 |
| 9 | 4.04.01.13.034 | Power Steering DC/DC Converter | 1 |
| 10 | 3.05.40.187 | Non-Isolated DC/DC Converter Mounting Plate | 1 |
| 11 | 4.04.06.12.123 | Front Headlight / RH | 1 |
| 12 | 3.06.06.08.001 | Front Cowl **Choose Color When Ordering** | 1 |
| 13 | 4.05.03.01.019 | White Pinstripe | 2 |
| | 4.05.03.01.018 | Black Pinstripe | |
| 14 | 4.04.06.12.122 | Front headlight / LH | 1 |
| 15 | 2.01.02.07.113 | Front Grille Logo | 1 |
| 16 | 4.05.01.41.017 | Grille | 1 |
| 17 | 4.05.01.29.070 | Trim Clip | 5 |
| 18 | 4.05.01.41.018 | Front Plastic Bumper | 1 |
| 19 | 4.04.07.145 - V2 | Push Button Start + 2 Fobs | 1 |
| 20 | 4.05.01.41.019 | Front Support / LH | 1 |
| 21 | 4.05.01.33.082 | Steering Column Lower Cover Plate | 1 |
| 22 | 4.05.01.41.014 | Front Retainer / LH | 1 |
| 23 | 4.05.01.01.068 | Disc Brake Pedal Frame Cover | 1 |

# DASH PANEL





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 1 | 4.05.01.41.021 | Dash Panel | 1 |
| 2 | 4.04.06.37.014 | Storage Box Light 12v | 1 |
| 3 | 4.05.01.41.024 | Middle Storage Box | 1 |
| 4 | 4.04.14.02.005 | Cigar Lighter Base | 1 |
| 5 | 4.05.01.41.026 | Dashboard Panel Shroud | 1 |
| 6 | 4.04.02.01.059 | KCD1 Peephole Switch | 2 |
| 7 | 4.04.06.37.019 | RNF Knob | 1 |
| 8 | 4.04.01.06.042 | USB Plug | 1 |
| 9 | 4.05.01.41.032 | Storage Box Cover Base | 1 |
| 10 | 4.05.01.41.025 | Storage Box / RH | 1 |
| 11A | 4.05.01.41.023 | Cup Holder / RH | 1 |
| 11B | 4.05.01.41.022 | Cup Holder / LH | 1 |
| 12 | 4.04.06.37.001 | Cup Holder Luminous Pad LED | 4 |
| 13 | 4.04.02.02.022 | Lock Set | 1 |
| 14 | 4.05.01.41.031 | Storage Box Cover | 1 |
| 15 | 3.02.01.69.078 | Display Installation Plate | 1 |

# DASH PANEL *CONTINUED*





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 16 | 4.04.06.37.020 | 10.3” Display | 1 |
| 17 | 4.05.01.41.030 - V2 | Display Rear Support | 1 |
| 18 | 4.04.06.37.005 | Display Amplifier | 1 |
| 19 | 3.02.01.08.038 | Display Amplifier Housing Mounting Plate | 1 |
| 20 | 4.04.06.13.067 - Gen 2 | Cup Light Control Panel | 2 |
| 21 | 4.05.04.09.049 | Speaker Bass Reflex Tube | 2 |
| 22 | 4.05.01.41.043 | Cavity Base | 2 |
| 23 | 4.05.01.41.044 | Cavity Cover | 2 |
| 24 | 4.05.01.41.027 | Front Speaker Mounting Bracket | 2 |
| 25 | 4.04.06.37.003 | Speaker | 2 |
| 26 | 4.04.06.33.005 | Speaker Sealing Gasket | 2 |
| 27 | Only Available As Assembly | Speaker Cover (Including Light Strip) | 2 |
| 28 | 4.04.06.37.011 | Front Dash Speaker Assembly | 1 |
| 29 | 4.04.02.11.002 | Hazard Light Switch | 1 |
| 30 | 4.01.42.008 | Storage Box Cover EVA | 1 |

# PEDAL ASSEMBLY





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 1 | 4.05.01.01.118 | Front Disc-Brake Pedal Box Support | 1 |
| 2 | 4.02.02.10.064 | Brake Disc Pedal Pad | 1 |
| 3 | 4.05.01.41.146 | Front Floor Mat | 1 |
| 4 | 4.05.01.41.147 | Rear Floor Mat | 1 |
| 5 | 4.05.01.01.010 | Pedal Base Lid | 1 |
| 6 | 4.02.02.10.011 | Brake Pedal Pad (STOP) | 1 |
| 7 | 4.02.02.10.012 | Accelerator Pedal Pad (GO) | 1 |
| 8 | 2.01.02.02.003 | Accelerator | 1 |
| 9 | 4.02.05.01.018 | Master Cylinder | 1 |
| 10 | 2.01.01.03.318 | Brake Disc Pedal Assembly | 1 |

# CHASSIS





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 1 | 3.02.01.69.072 | Rear Trunk Base | 1 |
| 2 | 4.02.02.03.016 | Electromagnetic Parking Brake Cable | 1 |
| 3 | 3.02.01.69.058 | Rear Seat Base | 1 |
| 4 | 3.02.01.03.006 | Outrigger | 1 |
| 5 | 3.05.80.059 | Front Underbody | 1 |
| 6 | 4.05.01.41.092 | Steering Wheel Control Cover / LH | 1 |
| 7 | 4.04.06.37.023 | Steering Wheel Control / LH | 1 |
| 8 | 4.04.06.37.024 | Steering Wheel Control / RH | 1 |
| 9 | 4.05.01.41.093 | Steering Wheel Control Cover / RH | 1 |
| 10 | 4.02.01.03.056 | Steering Wheel | 1 |
| 11 | 4.05.01.41.084 | Steering Wheel Micro Switch Mounting Bracket | 1 |
| 12 | 4.04.07.174 | Steering Wheel Base Contact Points | 2 |
| 13 | 4.04.07.145 - V2 | Push Button Start + 2 Fobs | 1 |
| 14 | 4.05.01.01.129 | Steering Column Rubber Pad | 6 |
| 15 | 4.05.01.41.070 | Steering Column Cover / RH | 1 |
| 16 | 4.05.01.41.071 | Steering Column Cap | 1 |
| 17 | 4.02.01.01.099 | Adjustable Steering Column | 1 |
| 18 | 4.03.07.292 | Micro-Bearing Wire Rope | 1 |
| 19 | 4.05.01.41.073 | Pole Tension Bolt | 1 |
| 20 | 4.05.01.41.072 | Steering Column Cover / LH | 1 |
| 21 | 4.04.14.01.007 | Combination Switch | 1 |

# CHASSIS *CONTINUED*





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 22 | 4.05.01.41.074 | Lamp Rubber Light Control Cap | 1 |
| 23 | 3.05.80.036 | Column Lamp Control Fixing Plate | 1 |
| 24 | 4.05.01.41.137 | Front Side Strip Trim Cover / RH | 1 |
| 25 | 3.02.01.69.084 | Middle Retainer | 2 |
| 26 | 2.06.01.01.007 | Main Beam Assembly | 1 |
| 27 | 4.05.01.41.136 | Front Side Strip Trim Cover / LH | 1 |
| 28 | 4.05.03.35.016 | “BINTELLI” Retainer Logo | 2 |
| 29 | 4.02.02.12.008 | Oil Pipe Clamp | 2 |
| 30 | 4.05.01.41.112 | Middle Retainer Cover | 1 |
| 31 | 4.04.06.37.026 | Retainer Light Bar | 2 |
| 32 | 4.05.03.01.058 | “NEXUS” Retainer Logo | 2 |
| 33 | 2.06.03.03.012 | ARGB Light Controller | 1 |
| 34 | 4.04.01.13.045 | Isolated DC-DC Converter G-12036W500Y-6P | 1 |
| 35 | 3.05.14.093 | Controller Cable Hub | 1 |
| 36 | 3.05.80.054 | Controller Plate | 1 |
| 37 | 4.04.01.05.078 | Controller | 1 |
| 38 | 4.04.06.10.025 | Ceramics Fuse Seat | 1 |
| 39 | 4.04.06.10.012 | Fuse 400A | 1 |
| 40 | 3.05.80.055 | Contactor Copper Bar | 1 |
| 41 | 4.04.01.12.024 | Contactor | 1 |
| 42 | 2.01.02.23.027 | C Board Controller Assembly | 1 |

# FRONT AXLE





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 1 | 4.05.04.07.004-V2 | Brake Reservoir | 1 |
| 2 | 3.02.01.17.016 | Brake Reservoir Bracket | 1 |
| 3 | 3.02.01.01.124 | Front Underbody Support | 1 |
| 4 | 3.02.01.01.221 | Power Steering System Controller Mounting Plate | 1 |
| 5 | 3.02.01.33.051 | Front Axle | 1 |
| 6 | 4.04.07.185 | Electronic Power Steering System Controller / 1.3 | 1 |
| 7 | 4.04.02.06.021 | Horn 12V | 1 |
| 8 | 3.02.01.01.008 | Front Trailer Bracket | 1 |
| 9 | 4.02.01.01.046 | Universal Joint Assembly | 1 |
| 10 | 3.02.01.69.001 | Front Fixed Plate | 1 |
| 11 | 4.02.01.01.043 | Steering Rack Boot | 2 |
| 12 | 4.02.01.01.044 | Tie Rod End | 2 |
| 13 | 4.02.01.01.103 | Electronic Power Steering System Assembly / 1.3 (Tie Rod Ends Not Included) | 1 |

# FRONT AXLE LH





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 1 | 4.02.07.03.006 | Valve Stem | 1 |
| 2 | 4.02.07.04.013 | Hub Cap | 1 |
| 3 | 4.02.07.02.051 | Aluminum Rim | 1 |
| 4 | Beyond/Nexus Tire | Tire 215/35 R14 | 1 |
| 5 | 4.05.04.03.006 | Hub Grease Cap | 1 |
| 6 | 4.03.04.03.007 | Split Nut M20*1.5 | 1 |
| 7 | 4.03.04.03.003 | Aluminum Wheel/Rim Nut / 1/2-20 | 4 |
| 8 | 4.02.02.10.063 | Brake Disc | 1 |
| 9 | 4.03.02.02.004 | Hub Screw 1/2-20*41 | 4 |
| 10 | 4.02.01.01.037 | Hub Assembly | 1 |
| 11 | 4.02.05.01.038 | Front Caliper / LH | 1 |
| 12 | 4.02.05.03.003 | Brake Pads (Set of 2) | 1 |

# FRONT AXLE LH *CONTINUED*





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 13 | 4.02.02.10.006 | Disc-Brake Spindle / LH | 1 |
| 14 | 3.02.01.01.234 | Moving Rocker Arm Lower Moving Plate / RH | 1 |
| 15 | 4.03.05.03.027 | Camber Washer 0 | 3 |
| 16 | 3.02.01.01.233 | Moving Rocker Arm Lower Moving Plate / LH | 1 |
| 17 | 4.02.04.01.079 | Tie Rod | 1 |
| 18 | 4.03.04.02.013 | Rocker Arm Ball Head Nut | 1 |
| 19 | 4.02.01.01.018 | Spindle Shaft Base | 1 |
| 20 | 4.03.06.05.011 | Pin Opening M2.5*30 | 1 |
| 21 | 4.03.01.02.014 | Bearing 32005 | 2 |
| 22 | 4.05.04.01.008 | Oil Seal / Hub 30*47*8mm | 1 |
| 23 | 4.02.04.04.003 | TF-4 Damper | 1 |
| 24 | 4.02.04.01.017 | A4 Spring | 1 |
| 25 | 2.01.01.02.017 | Front Shock Absorber Assembly TF-4 | 1 |

# FRONT AXLE RH





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 1 | 4.02.07.04.013 | Hub Cap | 1 |
| 2 | 4.02.07.03.006 | Valve Stem | 1 |
| 3 | 4.02.07.02.051 | Aluminum rim | 1 |
| 4 | Beyond/Nexus Tire | Tire 215/35 R14 | 1 |
| 5 | 4.05.04.03.006 | Hub Grease Cap | 1 |
| 6 | 4.03.04.03.007 | Split Nut M20*1.5 | 1 |
| 7 | 4.03.04.03.003 | Aluminum Wheel/Rim Nut / 1/2-20 | 4 |
| 8 | 4.02.02.10.063 | Brake Disc | 1 |
| 9 | 4.03.02.02.004 | Hub Screw 1/2-20*41 | 4 |
| 10 | 4.02.01.01.037 | Hub Assembly | 1 |
| 11 | 4.03.01.02.014 | Bearing 32005 | 2 |
| 12 | 4.05.04.01.008 | Oil Seal / Hub 30*47*8mm | 1 |

# FRONT AXLE RH *CONTINUED*





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 13 | 4.03.06.05.011 | Pin.Opening/M2.5*30 | 1 |
| 14 | 4.03.04.02.013 | Rocker Arm Ball Head Nut | 1 |
| 15 | 4.02.04.01.079 | Tie Rod | 1 |
| 16 | 3.02.01.01.234 | Moving Rocker Arm Lower Moving Plate RH | 1 |
| 17 | 4.03.05.03.027 | Camber Washer 0 | 3 |
| 18 | 3.02.01.01.232 | Moving Rocker Arm Upper Board LH/RH | 1 |
| 19 | 4.02.02.10.007 | Disc-Brake Spindle/RH | 1 |
| 20 | 4.02.01.01.018 | Spindle Shaft Base | 1 |
| 21 | 4.02.05.01.039 | Front Caliper / RH | 1 |
| 22 | 4.02.05.03.003 | Front Brake Pad | 2 |
| 23 | 4.02.04.04.003 | TF-4 Damper | 1 |
| 24 | 4.02.04.01.017 | A4 Spring | 1 |
| 25 | 2.01.01.02.017 | Front Shock Absorber Assembly TF-4 | 1 |

# REAR AXLE TUBE





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 1 | 3.02.01.01.036 | Rear Stabilizer/Balance Bar | 1 |
| 2 | 3.02.01.01.099 | Rear Axle Tube Kit | 1 |
| 3 | 4.04.01.02.077 | 72V 5KW Motor | 1 |
| 4 | 4.04.01.03.041 | EM Brake | 1 |
| 5 | 3.02.01.01.195 | Bracket Rear Axle Tube | 2 |
| 6 | 4.04.01.02.073 | Nexus Motor with EM Brake | 1 |
| 7 | 4.02.10.034 | Rear Shock Absorber R-3 | 2 |
| 8 | 4.02.04.01.016 | Rear Spring | 2 |
| 9 | 2.01.01.02.018 | Rear Shock Absorber Assembly R-3+A4 | 2 |

# REAR TRANSAXLE





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 1 | 4.03.04.03.003 | Aluminum Wheel/Rim Nut / 1/2-20 | 8 |
| 2 | 4.02.07.03.006 | Valve Stem | 1 |
| 3 | 4.02.07.02.051 | Aluminum Rim | 2 |
| 4 | Beyond/Nexus Tire | Tire 215/35 R14 | 2 |
| 5 | 4.02.02.10.063 | Brake Disc | 2 |
| 6 | 4.02.06.02.042 | Transaxle Assembly | 1 |
| 7 | 4.02.05.01.037 | Rear Caliper / LH **Part Excludes Brake Pads** | 1 |
| 8 | 4.02.05.03.003 | Front Brake Pad (Set of 2) | 2 |
| 9 | 4.02.05.01.036 | Rear Caliper / RH **Part Excludes Brake Pads** | 1 |

# FRONT BACKREST ASSEMBLY





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 1 | 4.05.01.07.05.002 | Front Backrest Plate | 1 |
| 2 | 4.05.01.41.064 | Headrest Connecting Plate | 1 |
| 3 | 3.02.01.01.023 | Safety Belt U-Tube | 1 |
| 4 | 3.02.01.01.011 | Middle Seat Belt Mounting Bar | 1 |
| 5 | 4.05.01.41.080 | Backrest Middle Plastic Cap | 1 |
| 6 | 4.05.01.41.062 | Backrest Cover | 1 |
| 7 | 4.05.01.41.077 | Backrest Net RH/small | 1 |
| 8 | 4.05.01.41.076 | Backrest Net LH/small | 1 |
| 9 | 4.05.01.41.067 | Backrest Armrest | 2 |
| 10 | 4.05.01.41.066 | Backrest Cup Holder Lab Mat | 2 |
| 11 | 4.05.01.41.065 | Backrest Cup Holder | 2 |
| 12 | 4.05.01.41.063 | Backrest Cup Holder Mounting Base | 1 |
| 13 | 4.05.01.41.068 | Backrest Armrest Cap | 4 |

# FRONT BACKREST ASSEMBLY *CONTINUED*





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 14 | 4.05.01.41.078 | Large Backrest Net | 1 |
| 15 | 3.02.01.69.040 | Backrest Cup Holder Base Adapter Board | 1 |
| 16 | 4.05.01.16.015 | Complete 3pt Seatbelt | 2 |
| 17 | 3.02.01.69.041 | Seat Belt Adapter Plate | 1 |
| 18 | 4.05.04.03.099 | Square Pipe Plug 20*30 | 2 |
| 19 | 3.02.01.69.082 | Front Backrest Tube Assembly | 1 |
| 20 | 4.05.01.16.016 | Seat Belt Lock | 2 |
| 21 | 4.05.01.33.136 | Foldable Armrest / RH | 1 |
| 22 | 4.05.01.49.004 | Foldable Armrest Cover / RH | 1 |
| 23 | 2.06.02.01.028 | Foldable Armrest With Cover Assembly / RH | 1 |
| 24 | 4.05.01.33.135 | Foldable Armrest / LH | 1 |
| 25 | 4.05.01.49.003 | Foldable Armrest Cover / LH | 1 |
| 26 | 2.06.02.01.027 | Foldable Armrest With Cover Assembly / LH | 1 |

# FRONT SEAT ASSEMBLY





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 1 | 3.06.06.08.009 | Front Seat Bucket Upper Housing | 1 |
| 2 | 3.05.80.056 | Front Seat Bucket Bracket Assembly | 1 |
| 3 | 2.01.02.10.005 | Communication Port | 1 |
| 4 | 4.05.03.01.042 | Tow/Run Switch Label | 1 |
| 5 | 4.04.02.01.009 | Tow/Run Switch | 1 |
| 6 | 4.05.04.02.015 | Seat Cushion Lower Silicone Pad (Oval) | 8 |
| 7 | 4.05.01.33.138 | A60 Seat Bucket Cover/LH | 1 |
| 8 | 4.05.01.01.038 | Seat Cushion Base Plate | 1 |
| 9 | 4.05.01.07.05.003-Black G2 | Seat Cushion | 1 |
| 10 | 4.01.68.008 | Flip Seat Pull Strap | 2 |
| 11 | 4.05.01.33.139 | A60 Seat Bucket Cover/RH | 1 |
| 12 | 3.05.40.0105 | Seat Cushion Latch (Upper) | 2 |
| 13 | 3.05.40.0106 | Seat Cushion Latch (Lower) | 2 |
| 14 | 3.05.80.077 | Front Seat Cushion Latch Lower Spacer / Aluminum | 2 |
| 15 | 3.06.06.08.008 | Front Seat Bucket Upper Housing | 1 |
| 16 | 4.05.03.01.016 | White Pinstripe | 1 |
| | 4.05.03.01.015 | Black Pinstripe | |
| 17 | N/A | Battery | 1 |
| 18 | N/A | Battery Charger | 1 |

# REAR BACKREST





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 1 | 4.05.01.15.003 | Golf Bag Strap | 1 |
| 2 | 4.05.01.15.004 | Golf Bag Rack | 1 |
| 3 | 4.05.01.15.012 | Golf Bag Strap Buckle | 2 |
| 4 | 3.02.01.69.076 | Plastic Golf Bag Rack Center Mounting Plate | 1 |
| 5 | 4.05.01.16.024 | 3-point seat belt | 2 |
| 6 | 4.05.04.03.001 | Square Pipe Plug 25*25 | 4 |
| 7 | 3.02.01.69.046 | Rear Armrest Seat Belt Bracket | 1 |
| 8 | 3.02.01.69.083 | Rear Support Assembly | 1 |
| 9 | 4.05.01.16.025 | Seat Belt Lock | 2 |
| 10 | 4.05.01.07.05.002 | Front Backrest Plate | 1 |
| 11 | 4.05.01.01.133 | Backrest Connection Plate | 2 |
| 12 | 4.05.01.41.064 | Headrest Connecting Plate | 1 |
| 13 | 4.05.01.01.130 | Backrest Base | 1 |
| 14 | 3.02.01.69.071 | Rear Support - Diagonal Brace/RH | 1 |

# REAR BACKREST *CONTINUED*





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 15 | 3.02.01.69.070 | Rear Support - Diagonal Brace/LH | 1 |
| 16 | 3.02.01.69.081 | Rear Seat Belt Support Tube | 1 |
| 17 | 4.05.04.03.055 | Square Pipe Plug 20*30 | 2 |
| 18 | 2.06.02.01.048 | Golf Bag Holder Assembly | 1 |
| 19 | 4.05.01.18.010 | Seat Holder Support | 2 |
| 20 | 4.05.01.18.009 | Seat Holder Movable Part | 2 |
| 21 | 4.05.01.18.008 | Seat Holder Base | 2 |
| 22 | 2.01.01.01.019 | Seat Holder Assembly | 2 |
| 23 | 4.05.01.33.136 | Foldable Armrest RH | 1 |
| 24 | 4.05.01.49.004 | Foldable Armrest Cover RH | 1 |
| 25 | 2.06.02.01.028 | Foldable Armrest With Cover Assembly RH | 1 |
| 26 | 4.05.01.49.003 | Foldable Armrest Cover LH | 1 |
| 27 | 4.05.01.33.135 | Foldable Armrest LH | 1 |
| 28 | 2.06.02.01.027 | Foldable Armrest With Cover Assembly LH | 1 |

# REAR SEAT AND BODY PANEL





| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 1 | 4.05.01.41.127 | Bumper Inner Liner / LH | 1 |
| 2 | 4.05.01.41.128 | Bumper Inner Liner / RH | 1 |
| 3 | 4.05.01.41.134 | Inner Fender / LH | 1 |
| 4 | 4.05.01.41.135 | Inner Fender / RH | 1 |
| 5 | 4.05.01.41.107 | Rear Side Strip Trim Cover / LH | 1 |
| 6 | 4.04.06.13.088 | Front Backrest Light Strip Hub PCB | 1 |
| 7 | 4.05.01.41.108 | Rear Side Strip Trim Cover / RH | 1 |
| 8 | 4.04.01.07.102 | Charging Socket | 1 |
| 9 | 4.05.01.41.106 | Step Side Strip | 1 |
| 10 | 4.04.06.37.028 | Subwoofer Light Strip | 2 |
| 11 | 4.05.01.41.110 | Speaker Front Grille | 2 |
| 12 | 4.05.01.41.105 | Rear Grille Front Trim | 1 |
| 13 | 4.04.06.37.025 | 5.25" External Magnet Subwoofer | 2 |
| 14 | 4.05.01.41.109 | Sound Chamber | 2 |
| 15 | 3.05.40.0106 | Seat Cushion Latch (Lower) | 2 |
| 16 | 3.05.40.0105 | Seat Cushion Latch (Upper) | 2 |
| 17 | 4.05.01.01.038 | Seat Cushion Base Plate | 1 |

# REAR SEAT AND BODY PANEL *CONTINUED*




| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 18 | 4.05.04.02.015 | Seat Cushion Seat Pads 3MM | 10 |
| 19 | 4.05.01.07.05.003-Black G2 | Rear Seat Cushion | 1 |
| 20 | 4.05.01.41.142 | Controller Cover Panel | 1 |
| 21 | 4.01.68.008 | Flip Seat Pull Strap | 2 |
| 22 | 4.05.01.41.133 | Pillar Trim Cover / RH | 1 |
| 23 | 4.05.01.41.116 | Pillar Trim Cover / LH | 1 |
| 24 | 4.05.03.01.040 | Body Beltline Decal | 2 |
| 25 | 4.04.14.01.005 | Rear Tail Light / RH | 1 |
| 26 | 4.05.01.41.115 | Tail Light Trim Strip / RH | 1 |
| 27 | 4.05.01.41.114 | Tail Light Trim Strip / LH | 1 |
| 28 | 4.04.14.01.004 | Rear Tail Light / RH | 1 |
| 29 | 4.05.01.41.113 | Service Access Cover Panel | 1 |
| 30 | 3.06.06.08.005 | Rear Cover | 1 |
| 31 | 4.04.06.12.025 | License Plate Light | 1 |
| 32 | 4.08.04.013 | AHD HD Backup Camera | 1 |
| 33 | 4.05.03.01.041 | Reflective Decal | 1 |
| 34 | 4.05.01.41.111 | Rear Bumper | 1 |

# REAR TRUNK




| No. | Part Number | Description | Pieces |
|---|---|---|---|
| 1 | 4.05.01.41.122 | Trunk Lid / Top Cover | 1 |
| 2 | 4.01.43.082 | Push-Button Latch | 1 |
| 3 | 4.05.01.41.119 | Trunk Cover Panel | 1 |
| 4 | 4.05.01.41.124 | Trunk Handle / RH | 1 |
| 5 | 4.05.01.41.120 | Trunk Lid Liner Panel | 1 |
| 6 | 4.05.01.41.125 | Retainer Plate / Clamp Plate | 2 |
| 7 | 4.05.01.41.143 | Anti-Vibration Rubber Plug | 14 |
| 8 | 4.05.01.41.123 | Trunk Handle / LH | 1 |
| 9 | 4.05.01.41.121 | Trunk | 1 |
| 10 | 4.05.01.41.126 | Knob | 3 |
| 11 | 2.06.02.01.049 | Rear Trunk Assembly | 1 |