



Bintelli Beast 49cc Parts List

Last Revision 10/2019




Bintelli Scooters
2137 Savannah Highway
Charleston, SC 29414
(843) 531-6833 Phone
www.BintelliScooters.com
www.BintelliParts.com

F1: FRAME AND FOOTREST

This diagram illustrates the exploded view of a bicycle frame and footrest assembly. The components are numbered 1 through 18, indicating their relative positions and assembly sequence. The frame (1) is the central component, with the head tube (2) and seat tube (3) visible. The down tube (4) and chain stays (5) are also shown. The footrest (6) is attached to the frame via a bracket (7). The pedals (8) are shown attached to the crank arms (9). The rear wheel assembly (10) includes the rear hub (11), spokes (12), and the rear fender (13). The front wheel assembly (14) includes the front hub (15), spokes (16), and the front fender (17). The handlebars (18) are shown at the top of the frame.


[illegible]

F2: SHOCK ABSORBER




No	Part Number (Vin starts with LLO)	Part Number (Vin starts with LLP)	Description	Qty
1	JHM30201	JHM30201	Triple Tree	1
2	JHM30202	JHM30202	Triple Tree Bearings	1
3	GST30203	JHM30203	Right Shock Absorber	1
4	GST30204	JHM30204	Left Shock Absorber	1
5	GST30205	JHM30205	Rear Shock Absorber	1
6	JHM30206	JHM30206	Rear Shock Absorber Bolt	1
7	JHM30207	JHM30207	Rear Shock Absorber Nut	1
8	JHM30208	JHM30208	Front Wheel Axle	1
9	JHM30209	JHM30209	Front Wheel Axle Bushine	1
10	JHM30210	JHM30210	Front Wheel Axle Cap	1
11	GST30211	JHM30211	Ignition lock Set	1
12	GST30212	JHM30212	Muffler	1
13	JHM30213	JHM30213	Front Brake Assembly	1
14	JHM30214	JHM30214	Brake Hose Clip	1
15	JHM30215	JHM30215	Steering Stem Nut	1
	JHM30216	JHM30216	Muffler Cover	1
	JHM30217	JHM30217	Bent Pipe	1

F3: HANDLE BAR AND SWITCH



No	Part Number (Vin starts with LLO)	Part Number (Vin starts with LLP)	Description	Qty
1	JHM30301	JHM30301	Handlebar	1
2	JHM30302	JHM30302	Upper Handlebar Clamp	2
3	JHM30303	JHM30303	Lower Handlebar Clamp	2
4	JHM30304	JHM30304	Beast Handlbar Clamp Rubber	2
5	JHM30304	JHM30304	Beast Handlbar Clamp Rubber	2
6	JHM30306	JHM30306	Left Grip	2
7	JHM30307	JHM30307	Right Grip (Throttle Grip)	1
8	JHM30308	JHM30308	Balance Weight	1
9	JHM30309	JHM30309	Upper Triple Tree Plate	1
10	JHM30310	JHM30310	Upper Triple Tree Bolt	1
11	GST30311	JHM30311	Left Switch Assembly	1
12	GST30312	JHM30312	Right Switch Assembly	1
13	JHM30313	JHM30313	Left Mirror	1
14	JHM30314	JHM30314	Right Mirror	1
15	GST30315	JHM30315	Beast Rear Brake Lever Assembly	1
16	JHM30316	JHM30316	Throttle Cable	1
17	JHM30317	JHM30317	Seat Lock Cable	1
18	JHM30318	JHM30318	Rear Brake Cable	1
19	JHM30319	JHM30319	Speedometer Wire and Gear Assembly	1
20	JHM30320	JHM30320	Bar Clamp Bolt	4
21	JHM30321	JHM30321	Bar Clamp Washer	2
22	JHM30322	JHM30322	Bar Clamp Nut	2

F4: Seat and Fuel Tank and Wheels



No	Part Number (Vin starts with LLO)	Part Number (Vin starts with LLP)	Description	Qty
1	JHM30401	JHM30401	Seat	1
2	GST30402	GST2018F350060	Rear Tire	1
3	GST2018F350062	GST2018F350062	Valve Stem	1
4	JHM30404	JHM30404	Rear Rim (Wheel)	1
5	JHM30405	JHM30405	Fuel Tank	1
6	JHM30406	JHM30406	Fuel Sensor	1
7	GST2018F350091	GST2018F350091	Fuel Petcock	1
8	GST2018F350090	GST2018F350090	Fuel Filter (In-Line)	1
9	GST2018F350084	GST2018F350084	Fuel Line	3
10	GST2018F350086	GST2018F350086	Vacuum Line	2
11	JHM30411	JHM30411	Fuel Tank Front Rubber	2
12	JHM30412	JHM30412	Fuel Tank Cover Rubber	1
13	JHM30413	JHM30413	Fuel Tank Rear Rubber	2
14	JHM30414	JHM30414	Rear Wheel Bushing	2
15	JHM30415	JHM30415	Rear Nut	1
16	JHM30416	JHM30416	Left and Right Cover Ring	4
17	JHM30417	JHM30417	Left and Right Protection Rubber Ring	2
18	JHM30418	JHM30418	Rear License Plate Fixing Rubber	1
19	JHM30419	JHM30419	Upper Block Water Proof Rubber	4
20	JHM30420	JHM30420	Headlight Fixing Rubber	2
21	JHM30421	JHM30421	Tie	6
22	JHM30422	JHM30422	Tie	2
23	JHM30425	JHM30425	Rear Wheel Shaft Cap	1

F5: PLASTIC PARTS-1

[illegible]

F6: PLASTIC PARTS-2




No	Part Number (Vin starts with LLO)	Part Number (Vin starts with LLP)	Description	Qty
1	JHM30601-JH005	JHM30601-JH005	Wind Cover (Black)	1
.	JHM30601-JH010	JHM30601-JH010	Wind Cover (Green)	1
.	JHM30601-JH021	JHM30601-JH021	Wind Cover (Burgundy)	1
2	JHM30602-JH005	JHM30602-JH005	Headlight Cover (Black)	1
.	JHM30602-JH010	JHM30602-JH010	Headlight Cover (Green)	1
.	JHM30602-JH021	JHM30602-JH021	Headlight Cover (Burgundy)	1
3	JHM30603	JHM30603	Upper Front Fender	1
4	JHM30604-JH005	JHM30604-JH005	Lower Front Fender (Black)	1
.	JHM30604-JH010	JHM30604-JH010	Lower Front Fender (Green)	1
.	JHM30604-JH021	JHM30604-JH021	Lower Front Fender (Burgundy)	1
5	JHM30605-JH005	JHM30605-JH005	Lower Left Front Fender (Black)	1
.	JHM30605-JH010	JHM30605-JH010	Lower Left Front Fender (Green)	1
.	JHM30605-JH021	JHM30605-JH021	Lower Left Front Fender (Burgundy)	1
6	JHM30606-JH005	JHM30606-JH005	Lower Right Front Fender (Black)	1
.	JHM30606-JH010	JHM30606-JH010	Lower Right Front Fender (Green)	1
.	JHM30606-JH021	JHM30606-JH021	Lower Right Front Fender (Burgundy)	1
7	JHM30607	JHM30607	Front Left Turn Light Connection Plate	1
8	JHM30608	JHM30608	Front Right Turn Light Connection Plate	1
9	JHM30609	JHM30609	Beast Right Upper Protection Plate	1
10	JHM30610-JH005	JHM30610-JH005	Right Mid Protection Plate (Black)	1
.	JHM30610-JH010	JHM30610-JH010	Right Mid Protection Plate (Green)	1
.	JHM30610-JH021	JHM30610-JH021	Right Mid Protection Plate (Burgundy)	1
11	JHM30611	JHM30611	Seat lock Cover	1
12	JHM30612-JH005	JHM30612-JH005	Right Mid Connection Plate (Black)	1
.	JHM30612-JH010	JHM30612-JH010	Right Mid Connection Plate (Green)	1
.	JHM30612-JH021	JHM30612-JH021	Right Mid Connection Plate (Burgundy)	1

F6: PLASTIC PARTS-2




No	Part Number (Vin starts with LLO)	Part Number (Vin starts with LLP)	Description	Qty
13	JHM30613-JH005	JHM30613-JH005	Right Lower Protection Plate (Black)	1
.	JHM30613-JH010	JHM30613-JH010	Right Lower Protection Plate (Green)	1
.	JHM30613-JH021	JHM30613-JH021	Right Lower Protection Plate (Burgundy)	1
14	JHM30614	JHM30614	Left Upper Protection Plate	1
15	JHM30615-JH005	JHM30615-JH005	Left Mid Protection Plate (Black)	1
.	JHM30615-JH010	JHM30615-JH010	Left Mid Protection Plate (Green)	1
.	JHM30615-JH021	JHM30615-JH021	Left Mid Protection Plate (Burgundy)	1
16	GST30616	JHM30616	OIL NEEDLE HOLE COVER	1
17	JHM30617-JH005	JHM30617-JH005	Right Mid Protection Plate (Black)	1
.	JHM30617-JH010	JHM30617-JH010	Right Mid Protection Plate (Green)	1
.	JHM30617-JH021	JHM30617-JH021	Right Mid Protection Plate (Burgundy)	1
18	JHM30618-JH005	JHM30618-JH005	Left Lower Protection Plate (Black)	1
.	JHM30618-JH010	JHM30618-JH010	Left Lower Protection Plate (Green)	1
.	JHM30618-JH021	JHM30618-JH021	Left Lower Protection Plate (Burgundy)	1
19	JHM30619-JH005	JHM30619-JH005	Left Protection Cover (Black)	1
.	JHM30619-JH010	JHM30619-JH010	Left Protection Cover (Green)	1
.	JHM30619-JH021	JHM30619-JH021	Left Protection Cover (Burgundy)	1
20	JHM30620-JH005	JHM30620-JH005	Right Protection Cover (Black)	1
.	JHM30620-JH010	JHM30620-JH010	Right Protection Cover (Green)	1
.	JHM30620-JH021	JHM30620-JH021	Right Protection Cover (Burgundy)	1
21	JHM30621-JH005	JHM30621-JH005	Rear Connection Plate (Black)	1
.	JHM30621-JH010	JHM30621-JH010	Rear Connection Plate (Green)	1
.	JHM30621-JH021	JHM30621-JH021	Rear Connection Plate (Burgundy)	1

F7: ENGINE



No	Part Number (Vin starts with LLO)	Part Number (Vin starts with LLP)	Description	Qty
1	JHM30701	JHM30701	Engine	1
2	Carburetor-1-J	Carburetor-1-J	49cc Carburetor	1
3	GST30703	GST2018F350094	Air Box	1
4	GST30704	17211-B08-9100-J	Air Filter element	1
5	GST30705	JHM30705	MAIN CABLE	1
6	4312A-DGW-9000-J	4312A-DGW-9000-J	Brake Shoes	1
7	GST2018F350116	GST2018F350116	Battery	1
8	GST2018F350079	GST2018F350079	Ignition Coil	1
9	GST2018F350076	GST2018F350076	Starter Solenoid	1
10	GST2018F350074	GST2018F350074	Horn	1
11	KM2018Pollo0075	KM2018Pollo0075	Flasher Relay	1
12	GST2018F350077	GST2018F350077	CDI	1
13	GST2018F350075	31600-DGW-E000-J	Voltage Regulator	1
14	17560-AEA1-0000	17560-AEA1-0000	Dumping Valve	1
15	JHM30715	JHM30715	Carbon Tank	1
16	KW2017TR0119	KW2017TR0119	Tool kit	1
	JHM30717	JHM30717	Battery Tie Down (not imaged)	1

F8: LIGHTS AND METER



No	Part Number (Vin starts with LLO)	Part Number (Vin starts with LLP)	Description	Qty
1	JHM30801	JHM30801	Headlight Assembly	1
2	JHM30802	JHM30802	Front Left Turn Signal	1
3	JHM30803	JHM30803	Front Right Turn Signal	1
4	JHM30804	JHM30804	Rear Brake Light	1
5	JHM30805	JHM30805	Rear Left Turn Signal	1
6	JHM30806	JHM30806	Rear Right Turn Signal	1
7	JHM30807	JHM30807	License Plate Light	1
8	JHM30808	JHM30808	Speedometer	1
9	GST2018F350037	GST2018F350037	Reflector (Red Rectangle)	1
10	GST2018F350038	GST2018F350038	License Plate Bracket	1
11	JHM30811	JHM30811	Reflector (Red Round)	2
12	JHM30812	JHM30812	Reflector Nut	2
13	JHM30813	JHM30813	Reflector Cap	2
14	GST2018F350035	GST2018F350035	Reflector (Orange, Round)	2
	34901-F35-9000-Y	34901-F35-9000-Y	Headlight Bulb	1

F9: FRONT WHEEL

[illegible]