

F1: FRAME




No	Part No	Description
1	50100-AEA1-0000/50cc	FRAME BODY
2	8121-AEA1-0000-J	REAR-HANDRAIL
3	84701-AEA1-0000-J	BRKT NUMBER PLATE
4	5050A-AEA1-0000/50cc	STAND ASSY MAIN
5	53200-AEA1-0000-J	STEERING STEM
6	50530-AEA1-0000-J	BAR SIDE STAND
7	77230-AEA1-0000-J	LOCK BASE OF SEAT
8	77235-AEA1-0000-J	LOCK BASE OF SEAT
9	50350-AEA1-0000/50cc	HANGER OF ENGINE
10	53100-AEA1-0000-J	HANDLE BAR
11	77240-AEA1-0000-J	CABLE OF SEAT LOCK
12	8221-AEA1-0000-J	RUBBER,REAR-HANDRAIL
13	77210-AEA1-0000	SEAT PIN
14	33742-ACB1-0000-J	FRONT REFLECTOR
15	90117-AEA1-0050	Hanger shaft
16	50515-AEA1-0000-J	engine hanger plug
17	95014-AEA1-0000-J	SPRING OF SIDE STAND
18	50550-GT10-0000	SPRING OF MAIN STAND

All Bintelli Parts can be purchased on www.BintelliParts.com

F3: PLASTIC PARTS-2



18



19



20


No	Part No	Description
1	81260-AEA1-0000-J	LUGGAGE BOX ASSY
2	53208-AEA1-0000-J	DECORATED BOARD FR HANDLE
3	81251-AEA1-0000-J	LID CARB MAINT
4	50613-AEA1-0000-J	COVER UNDER
5	80151-AEA1-0000-J	COVER CENTER
6	80100-MT10-0000-J	FENDER RR TIRE
7	81132-AEA1-0000-J	LEG SHIELD-BELOW
8	50326-AEA1-0000-J	BATTERY COVER
9	81131-AEA1-0000-J	LEG SHIELD-TOP
10	80105-AEA1-0000-J	REAR FENDER COVER
11	83750-AEA1-0000-J	TOP COVER,FUEL TANK
12	53206-AEA1-0000-J	COVER RR HANDLE
13	80109-AEA1-9300-J	REAR FENDER
14	80150-AEA1-0000-J	WATER-BLOCKING PARTS
15	64310-AEA1-0000-J	FLOOR PANEL
16	64220-AEA1-0000-J	WIND SCREEN
17	61110-ABEC-0000-J	FRONT FENDER EXTEND PLATE
18	81134-AEA1-0000-J	HOOK LUGGAGE
19	80152-AEA1-0000-J	CLIP ASSY CENTER
20	81133-AEA1-0000-J	VIN PLASTIC COVER

F6: FUEL TANK



No	Part No	Description
1	17501-AEA1-0000	FUEL TANK
2	3780A-AEA1-0000-J	FUEL SENSOR ASSY
3	17502-AEA1-0000	FUEL TANK CAP
4	16950-AEA1-0000	AUTO COCK ASSY FUEL
5	16910-F8-9000-J	STRAINER ASSY FUEL
6	16911-AEA1-0000	FUEL TUBE A
7	16914-AEA1-0000	FUEL TUBE D
8	17550-AEA1-0000	Carbon tank
9	17560-AEA1-0000	Dumping valve
10	77200-AEA1-0000	SEAT

F8: LOCK



No	Part No	Description
1	88120-AEA1-0000-J	MIRROR ASSY L/R BACK
2	3520B-AEA1-0000	Throttle block
3	53166-AEA1-0000-J	L.GRIP,HANDLE
4	53140-AEA1-0000-J	THROTTLE GRIP,HANDLE
5	17910-AEA1-0000-J	THROTTLE CABLE
6	44831-AEA1-0000-J	MILEAGE CABLE
7	35101-AEA1-0000-J	MAIN LOCK ASSY
8	35110-AEA1-0000	Seat lock brackct
9	35120-AEA1-0000	Seat lock
10	35130-AEA1-0000	Seat lock
11	53221-AEA1-0000-J	BOWL 2
12	53222-AEA1-0000-J	BOWL 2
13	53224-AEA1-0000-J	BOWL 3
14	53220-AEA1-0000-J	BALL ASSY.,down
15	53223-AEA1-0000-J	BALL ASSY.,UPPER
16	50305-AEA1-0000-J	TOP NUT,STEERING STEM A
17	50306-AEA1-0000-J	TOP NUT,STEERING STEM B

